

Hunter®

 **Hydrawise™ Ready**
IRRIGATION CONTROLLERS

Hydrawise Software/App Owner's Manual




hydrawise.com

Table of Contents

Table of Contents	2
Flow Meter Pressure Loss Chart	3
How to Configure Your Flow Meter	3
Flow Meter Installation Quick Start Guide	6
The flow meter consists of two parts:	6
The following instructions assume you have already installed your Hydrawise controller	7
Use your Hydrawise account to complete your flow meter configuration.	8
Flow Meter Installation Tips	9
HC Flow Meter Specifications	12
Reading Meter	13
Testing Flow Meter	14
How to Configure a Custom Flow Meter	16
Using One Flow Meter for Two Controllers	17
Winterization - Bypassing a Flow Meter	19
Wire Distance (Controller to Valve)	21
Pump Start Relay Wiring and Software Setup	22
One Master Valve - Two Controllers	27
Master Valve Wiring and Software Setup	28
Sprinklers Running with the Controller Off or Unplugged	33

Flow Meter Pressure Loss Chart

HC FLOW METER PRESSURE LOSS CHART




How to Configure Your Flow Meter

Assigning the Meter


:Please view the steps and screenshots to access this feature

1. Click on **SENSORS** from the home dashboard
2. Click on **ADD SENSOR TO CONTROLLER**
3. (Choose a **NAME**, **SENSOR TYPE**, and **INPUT** (flow-related only)
4. Choose which **ZONES** should be linked to the sensor
5. Click **OK** when finished

Step 1



Step 2



Step 3

Add Sensor

Sensor details

Set zones

Sensor Name

Assign a descriptive name for this sensor

Flow Meter

Type of Sensor

Choose the type of sensor you have installed. You can also create a custom sensor type if you have something non standard.

¾ inch NPT Flow Meter

Create New Sensor Type...

Controller Input

Choose the input on the controller that this sensor is wired to

SEN-1

Cancel

< Prev

Next >

✓OK

Step 4

Add Sensor

Sensor details

Set zones

Select Zones

Select the zones which will use this sensor

Available zones

Carioca Court

Back Grass

Back Drip

Diamond Street Controller

Front Grass

Front Flowers

Back Drip

Selected zones

Carioca Court

Front Grass

Street Drip

Front Drip

Cancel

< Prev

Next >

✓OK

Flow Meter Installation Quick Start Guide

In this Quick Start Guide, you will learn how to install and configure your flow meter. For support of Hydrowise™ cloud software or help with your Hydrowise account, visit the support [section here](#) ^[1]. For specification information, refer to the section [here](#) ^[2]

:The flow meter consists of two parts

Flowmeter body: The flowmeter body contains an analog dial for manual readings as **.1** follows. Your flow meter will have 3 wires protruding from the body. The wires need to be connected to the sensor inputs on the controller for readings in the software application. In **.all** models, only 2 wires (blue and white) are used

.Adapter: Each flow meter has an adapter to allow connection to your irrigation system **.2**

DIAL MARKING	MEASUREMENT UNIT
X0.01	0.1 gallon
X1	1 gallon
X10	10 gallons
X100	100 gallons

Flowmeter location: Flow meters are installed between the master valve and zone .3 valves. To avoid false alerts, there should be no water taps or other uncontrolled water use on the downstream side of the flow meter. If all solenoids connected to the controller are not grouped together, it may be necessary to install more than one flow meter. For proper installation and optimal water flow, use the chart below when determining pipe length. The pipe bringing water into the flow meter needs to be 10 times longer than the width of the .pipe. The pipe carrying water away from the meter needs to be 5 times the width of the pipe

PIPE	10X-BEFORE	5X-AFTER
¾"	7½"	3¾"
1"	10"	5"
1½"	15"	7½"
2"	20"	10"

Cable (shielded direct-burial cable must be used): Two-wire cable is required. The .4 cable gauge is determined by the total length of cable between the controller and the flow meter. The cable should consist of 2 dedicated wires and must not be in the same conduit or cable bunch as the solenoid wires. Do not share the common wire of the solenoids with the common of the sensors. If desired, the flex cable can be used to run inside the conduit. That .flex cable measures ¼" BSP, which also fits ¼" NPT


Flow Meter Cable Length Chart

WIRE SIZE	MAX LENGTH
Gauge	Feet
20	240
18	1,000

IMPORTANT: Shielded direct-burial cable is commonly available. Manufacturers include .Paige Electric and Regency Wire

The following instructions assume you have already installed your Hydrowise controller

Flowmeter body: The flow meter has a marking on the body indicating the direction of .1 water flow. Installation of the flow meter must be in the correct orientation with water flowing in the direction of the arrow on the flow meter body. All HC Flow Meters must be installed .horizontally with the dial facing upward




7

Connect flowmeter wire: Two-wire cable is required. The cable required to connect your .2 flow meter must be dedicated to the flow meter and not shared with the common wire of the valves or other sensors. The cable gauge is determined by the total length of cable between the controller and the flow meter. The general rule is that 0.5 mm (20GA) wire is good for a .run of up to 240'. Connect the wires to your Hydrawise controller

WIRE COLOR	SENSOR TERMINAL BLOCK
White	Common
Blue	Sen 1 or Sen 2
Red	Not used: Wires should be capped with waterproof splice

* Shield and bare wire should be connected to the controller ground terminal if available.



IMPORTANT: All wire connections should be done using waterproof connectors, such as 3M .316IR or 3M DBY

Use your Hydrawise account to complete your flow meter .configuration

.Log in to your account: Enter your login information .1

Create a flow sensor: It is important that you select the correct flow meter when .2 configuring your Hydrawise app. Choosing the wrong model may cause the Hydrawise controller to create false alerts in .the software

HC FLOW METER SELECTION CHART		
METER SIZE	DESCRIPTION	U.S. GALLON PULSE RATE
¾"	¾" flow meter	1 pulse per 0.1 gallon
1"	1" flow meter	1 pulse per 1 gallon
1½"	1½" flow meter	1 pulse per 1 gallon
2"	2" flow meter	1 pulse per 1 gallon


.Assign zones to the flow sensor: Refer to this [support article](#) ^[3] for setup information .3

Flow Meter Installation Tips


.Flow meters are supplied with [detailed installation instructions](#) ^[4]

The flow meter wires need to be cabled back to the controller and connected to the **Sensor** inputs on the controller. Check out the illustrations below for wiring standard Hydrawise flow ("meters to each of the model controllers (Sizes include ¾", 1", 1.5", and 2


HC




HCC




PRO-HC



HPC (Jan 2023 Newer)



HPC



The tips below include all the necessary key points of the installation to avoid any false alerts or readings.

Description		Installation Steps															
<p>Flow meters are designed to be installed horizontally only, with the dial facing up. Not vertically. Analog dial for manual readings in U.S. are shown in US gallons (Int. customers the dial reads in Cubic Meters). Units can be changed .in App to gallons or liters</p>		Flow Meter Body															
<p>.Brass unions included to fit your irrigation system</p>		Adapter															
<p>Install between the master valve and zone valves. Meter should be installed 10 times pipe diameter before and 5 times after with straight pipe and no fittings. :See example</p> <table><tr><th>5x-After</th><th>10x-Before</th><th>Pipe</th></tr><tr><td>"3.75</td><td>"7.5</td><td>"3/4</td></tr><tr><td>"5</td><td>"10</td><td>"1</td></tr><tr><td>"7.5</td><td>"15</td><td>"1.5</td></tr><tr><td>"10</td><td>"20</td><td>"2</td></tr></table>		5x-After	10x-Before	Pipe	"3.75	"7.5	"3/4	"5	"10	"1	"7.5	"15	"1.5	"10	"20	"2	Entry Location
5x-After	10x-Before	Pipe															
"3.75	"7.5	"3/4															
"5	"10	"1															
"7.5	"15	"1.5															
"10	"20	"2															

gauge - 1000 foot max Length. Shielded direct 18 burial cable must be used. Cable should consist of two dedicated wires and must not be in the same conduit, cable bundle or trench as the solenoid wires. DO NOT share common wire. Shielded cable is commonly available, here are some manufacturers (Paige ^[5] & Regency ^[6] For additional information on avoiding electrical interference, see below	(Cable used (shielded cable only
.Arrow indicates direction of flow	Flow meter body
Blue/White wire only, red not used. See sensor configuration ^[7] for more info based on model .controller	Wire Connection
.Enter your login ^[8] information	Log in to your account
.App will show options for all HC meters	Create your flow sensor
See link here ^[9]	Creating Alerts
See link here ^[10]	Reading Meter
See link here ^[11]	Testing Meter


Avoid Electrical Interference

- .Always use shielded cable, between the controller and the HC Flow Meter
- At the controller end, using the shield (foil wrap) and the bare wire connect them to the .(controller GND terminal (not required for HC controllers
- Do not connect the other end of the Shield or the bare wire to the Earth or a grounding stake
- .Use Waterproof wire connectors at the flow meter, such as the [3M-DBOB](#) ^[12]
- Shielded cable is commonly available, here are some manufacturers. [Paige](#) ^[5] & [Regency](#) ^[6]

HC Flow Meter Specifications

HC FLOW METER SPECIFICATIONS

2" HC-200-FLOW	1 1/2" HC-150-FLOW	1" HC-100-FLOW	3/4" HC-075-FLOW	HC Flow Model
NPT body, male 2" thread	NPT body, male 1 1/2" thread	NPT body, male 1" thread	NPT body, male 3/4" thread	Inlet/outlet connection size
2"	1.5"	1"	3/4"	Meter internal diameter
1.98	0.88	0.3	0.22	Minimum flow (GPM)
105	66	30	15	Maximum recommended flow (GPM)
132	88	34	21	Maximum flow rate (GPM)
pulse per 1 U.S. gal 1	pulse per 1 U.S. 1 gal	pulse per 1 U.S. 1 gal	pulse per 0.1 U.S. 1 gal	Dial reading (US gal)
230	230	230	230	Maximum working pressure (PSI)
.total wire length with first 8" having flex conduit 29				Included Wire Length
Threading measures 1/4" BSP, which would also fit 1/4" NPT for all models. .The exact thread size of the stainless steel fitting is 1/4-28				Flex Conduit Thread Spec




Reading Meter

The Hydrowise flow meters come in a US Gallon reading for domestic and metric reading called M³ (Meters Cubed 1000 Liters) for international. The conversion rate for metric meters is 3.78 Liters to 1 US Gallon if required

:See an example of meter reading below in US gallons


Gallons 8100	X100	Fig. 1
814X.XX Gallons	X10	Fig. 2
XX Gallons.8142	X1	Fig. 3
8142.4X Gallons	X0.1	Fig. 4
Gallons Total 8142.46	X0.01	Fig. 5
"1	Size meter	Fig. 6
.Wheel spins when water is flowing	Flow Indicator	Fig. 7
40mm) & 2"(50mm) flow meter models) "1-1/2	Pulse Transmitter	Fig. 8

.We have a flow that has gone through the meter of 8,142.46 gallons



:See an example of meter reading below in Litres

	Litres 8,000	Fig. 1
	Litres 8,200	Fig. 2
	Litres 8,220	Fig. 3
	Litres 8,224	Fig. 4
	Litres Total 8,224.7	Fig. 5
	.The wheel spins when water is flowing	Fig. 6




So we have a flow that has gone through the meter of 8,224.7 Litres. To calculate this into
 .Gallons is easy $8,224.7 / 3.78 = 2175.84$ gallons

Testing Flow Meter

If your flow meter is working but is not recording data in your **Dashboard** or events, follow
 .the steps below for each test

- .1 .Make sure the sensor is configured ^[13] in the software
- .2 Make sure the controller is online. If not, please use this link ^[14] for Wi-Fi troubleshooting
- .3 .steps
- .4 .Remove the wire splices at the flow meter connection in the field
- .5 .Turn a zone on **MANUALLY** from the controller or the app
- .6 Tap the two wires together that run to the controller 10 times, as each contact will record
- .7 .a pulse. Refresh the app to see if the flow usage was registered
- .8 If the app registered flow usage, your wiring and system are set up correctly. Reconnect
- .9 to the flow meter and run a large flow (lots of sprinklers) zone. Did you get a flow on your
- .10 .app? If **YES**, all is OK. If **NO**, contact support@hydrowise.com ^[15]
- .11 If the app did not register flow usage, test the sensor inputs on the controller. You can
- .12 use the same method with a paper clip or wire to contact sensor 1 or 2 and the common
- .13 terminal. Do this 10 times and then check for flow data usage at the home screen. If
- .14 **YES**, there is a problem with the wire running to the flow meter. If **NO**, please contact
- .15 .support@hydrowise.com ^[15]



Test #2

- .1 .Take a photo of the flow meter **DIAL**
- .2 .”Make a note of the **TOTAL FLOW** from the report “Total Water Use
- .3 .Run the system for a day’s watering
- .4 .Take a second photo of the flow meter **DIAL**
- .5 .”Make another note of the **TOTAL FLOW** from the report “Total Water Use
- .6 .**CALCULATE** the amount of flow that went through the flowmeter
- .7 .Next, **CALCULATE** the amount of flow that Hydrowise shows
- .8 .**RECALIBRATE** the flowrate to suit the dial


IMPORTANT: Our controllers are not polarity sensitive. There is no risk of electric shock when performing these tests. However, if you feel uncomfortable, please contact a qualified technician or irrigation specialist for further assistance.

.NOTE: If it works at the controller end but not the flow-meter end, there is a wiring fault

How to Configure a Custom Flow Meter

If you choose to use a flow meter from another manufacturer with a reed switch output, please make sure the configuration is set up under **CUSTOM SENSOR TYPE**

.1 .Log in to the [Hydrawise app](#) [®]


.2 .Click the  **MENU** icon on the upper left-hand side

.3 .Select the  **SENSORS** option

.4 .Select **CUSTOM SENSOR TYPE**

.5 .Select **ADD CUSTOM SENSOR TYPE**

.6 A dialogue box will appear for you to enter your custom flow meter details. Make sure you enter the calibration details for your custom, pulse-based flow meter. Please refer to the manufacturer specifications to determine the calibration. Otherwise, you will not receive accurate readings to display on your flow data



NOTE: For our system to detect the correct flow data and reflect it on your **Dashboard** reports, any third-party flow meter used must be a true pulse flow meter or have a reed switch. We aim for a minimum of 10 pulses per min and a maximum of 120 pulses per min. That means if the flow rate was 10 gal per min, 1 pulse per gallon .needs to be set

When using a third-party flow meter, please ensure it meets the specs above and is calibrated correctly. Otherwise, data will not reflect accurately in reports. Also, note that the wiring is not polarity sensitive. As long as you have one wire in a **Sensor Port** and a **Sensor Common**, the device will work correctly. For flow meters that use three wires and meet the .specs above, configure the wiring until you find the two correct wires to use

Using One Flow Meter for Two Controllers

For this installation, we suggest a few tips to make sure you do not receive any unnecessary alerts.

When using two controllers on the same flow meter, there are two alerts we do not recommend using.

- . **HIGH FLOW LEAK** - High water usage with no zones running.
- . **SLOW LEAK** - Water usage over last hour with no zones running.

These alerts are controller specific so when the controller with the flow meter is not in operation, it does know about the other controller operation

Tips:

- . The inter station delay ^[16] should be set for 10-30 seconds. We do not recommend any higher.
- . Change the gallons in the alert to be **HIGHER** (e.g. alert from 5 gallons to 20 gallons).
- . Wire to only **ONE** of the two controllers.
- . Configure the sensor to the controller that has the wire connection.
- . Move **AVAILABLE** zones from both controllers into **SELECTED ZONES**.

. For more information on configuring and wiring, visit support section here ^[17]

The screenshot shows a web interface for configuring a sensor. At the top is a title bar 'Add Sensor' with a close button. Below it are two tabs: 'Sensor details' and 'Set zones', with 'Set zones' being the active tab. Under the 'Set zones' tab, the heading 'Select Zones' is followed by the instruction 'Select the zones which will use this sensor'. There are two main columns: 'Available zones' on the left and 'Selected zones' on the right. The 'Available zones' column is divided into two sections. The first section, 'HCC - Carioca Court Controller', contains a list of zones: 'Front Grass', 'Street Landscape', 'Front Landscape', 'Back Landscape', and 'Back Grass'. The second section, 'PRO-HC - Carioca Court', is currently empty. Blue arrows point from the 'Available zones' list to the 'Selected zones' area, indicating the process of moving zones. At the bottom of the window are four buttons: 'Cancel', '< Prev', 'Next >', and a green 'OK' button.

Following these parameters should allow the system to run normal when using one flow meter with multiple controllers

Winterization - Bypassing a Flow Meter

:Overview


We recommend that a qualified licensed contractor perform this type of winterization method. The blowout method utilizes an air compressor with a cubic foot per minute (CFM) rating of 80-100 for any 2" or less mainline. The compressor is attached to the mainline via a quick coupler, hose bib, or other connections located beyond the backflow device. For additional winterization procedures, we highly recommend contacting the local dealer for the most common local practices.

IMPORTANT: Compressed air should not be blown through any backflow or flow meter device.

If you need to blow upstream from where the flow meter is located, we recommend bypassing the meter temporarily by using one of two options.

Bypass HC Flow Meter Using Nipple

.See the size chart below for specific lengths to install an SCH 80 or galvanized nipple




Nipple Length	Male-Thread NPT	Description	Model
"5	NPT "1	NPT body, male thread "3/4 with 1" NPT male adapter	HC-075-FLOW
"5	NPT"1/4 1	NPT body, male thread "1 with 1.5" NPT male adapter	HC-100-FLOW
"3/4 11	NPT"2	NPT body, male thread "1/21 with 2" NPT male adapter	HC-150-FLOW
"3/4 11	BSP "1/2 2	NPT body, male thread "2 with 3" NPT male adapter	HC-200-FLOW

Bypass HC Flow Meter Using Shutoff Valves

A second option would be to install PVC tee-ball valves on each side of the meter. This is the recommended option during NEW installation. The meter will have to be removed manually after the blowout to make sure any residual water is not sitting inside through the .winter months

IMPORTANT: The pipe flowing water into the flow meter needs to be a **MINIMUM** of 10 times longer than the width of the pipe. The pipe flowing water away from the meter needs to .be a **MINIMUM** of 5 times the width of the pipe

- Ball Valve 1 .1
- Ball Valve 2 .2
- (Ball Valve 3 (Not necessary for winterizing but helpful for maintenance on the meter .3
- Bypass PVC pipe .4



Find a Hunter Distributor closest to you using our interactive lookup - [Get Hunter](#)¹⁸

(Wire Distance (Controller to Valve

The chart below indicates the maximum wire runs that can be used when installing Hunter AC solenoid valves with controllers. The example in the chart below demonstrates the most commonly used wire size for station control and ground wire (e.g., 12 AWG = 3390 feet

NOTE: Valve Wire Sizing (Maximum One-Way Distance in Feet Between Controller and (Valve

(Control Wire (FT						Ground Wire (size)
AWG / 3 8 mm	AWG / 2.5 10 mm	AWG / 2.0 12 mm	AWG / 1.6 14 mm	AWG / 1.2 16 mm	AWG / 1.0 18 mm	
1540	1460	1350	1210	1040	850	AWG / 1.0 18 mm
2330	2150	1920	1650	1340	1040	AWG / 1.2 16 mm
3450	3080	2630	2150	1650	1210	AWG / 1.6 14 mm
4880	4170	3390	2630	1920	1350	AWG / 2.0 12 mm
6670	5400	4170	3080	2150	1460	AWG / 2.5 10 mm
8700	6670	4880	3450	2330	1540	AWG / 3 mm 8

Pump Start Relay Wiring and Software Setup

:In this article, we will discuss the following topics

- Summary •
- Operation Chart •
- (Wiring (24 VAC •
- Wiring to Power Source •
- Software Setup •
- Pump Start Relay Operation per Zone •

Summary

When a system requires the use of a booster pump or pulls water directly from a creek or pond, it's imperative to include a relay to activate the pump each and every time. A pump

start relay is a relay box that activates a pump every time a zone is activated from the controller. Zone valves are the individual valves that operate a group of sprinklers or drip emitters. Hydrowise controllers support 6- to 54-zone valves, depending on the model. Typically, one zone valve is turned on at a time and controls the irrigation in a specific area of your landscape. Whenever one of the irrigation zone valves is told to open by the controller, the controller also signals the pump start relay to turn the pump on

Operation Chart

Set Master Valve Operation	Controller Model
ON or OFF by All Zones	HC
ON or OFF by All Zones	PRO-HC
ON or OFF by Zone or All Zones	X2 w/WAND WiFi Module
ON or OFF by Zone or All Zones	HPC
ON or OFF by Zone or All Zones	HCC

(Wiring (24 VAC

Use a minimum distance of 15' (4.5 m) between the controller and the relay to dampen electromagnetic noise. In addition to this recommendation, Hunter also recommends all controllers be mounted 15' (4.5 m) away from pumps and high-voltage devices

- Detach the pump start relay cover plate by removing the four screws with a .1
Phillips screwdriver
- Run a single wire from the "common" terminal on the controller to one of the yellow wires .2
on the pump start relay
- Run a single wire from the "P/MV" terminal on the controller to the other yellow wire on .3
the pump start relay
- .4
Use wire nuts to make the connections and verify they are secure
- .5
Install pump start relay cover plate and four screws. Close and lock the cabinet door
- .6
Route wire through the conduit or one of the openings on the bottom of the cabinet
- .7
Strip ½" (13 mm) of insulation from the ends of all wires. Secure the valve common wire
to the "COM" (Common) terminal. Attach the opposite control wire to the M/V terminal

Pump Start Relay Maximum Wire Lengths						
(!MAXIMUM one-way wire length (do not go this far						
AWG 8	AWG 10	AWG 12	AWG 14	AWG 16	AWG 18	Model
ft 2,463	ft 1,551	ft 976	ft 616	ft 386	ft 243	PSR-22

Connecting the pump start relay should only be done by a licensed electrician following local codes. Improper installation could result in shock or fire hazard

To prevent electric shock, turn the main circuit-breaker switch to “off” prior to making .1
.electrical connections

Assemble conduit piping and connect AC power from the power source to one side .2
.(LINE IN) of the relay

Assemble conduit piping and connect wiring from the pump motor to the other side of the .3
.(relay (LOAD OUT


.Check to make sure there are no exposed or loose connections .4

Software Setup

This setup option is prompted when you first go through the initial setup wizard in the .software

The online instructions will refer to a **MASTER VALVE** but this same setting applies when .(using a **PUMP START RELAY (PSR**

NOTE: With an HC Hydrowise controller, any one of your 6 or 12 zones can be configured to act as the pump start relay. We usually recommend wiring to the last zone that is not .being used in the controller




If you need to change this in the software after the setup wizard, refer to the instructions .below

Log in to your Hydrowise account .1

.Click on **ZONES AND SCHEDULES** for the PC or **ZONES** if using the mobile app .2

Choose **YES** from the drop-down menu above the zones. If you have an HC controller, .3
.choose the zone number to which you have the master valve wired



Pump Start Relay Operation per Station

When selecting a **PUMP START RELAY** to be on/off for an individual zone, you can edit the zone in **ZONES AND SCHEDULES** under **ADVANCED SETTINGS**. This option is useful when one zone is using city water and another is using water from a different source. This .option is for X2 w/WAND, HPC, and HCC controllers only


:Follow the steps below to change this setting

From the **ZONES AND SCHEDULES** page, click on the (🔍) icon on the zone you would .1
.like to edit

.Click on **ADVANCED**, which is located on the top blue search section .2

Select **USE GLOBAL MASTER VALVE SETTING** to keep this circuit on or select .3

.DISABLE MASTER VALVE to turn it off



One Master Valve - Two Controllers

There are many times when two controllers are being supplied from a single POC (point of connection) or source of water. Hydrowise-ready controllers can be connected to a single master valve using a isolation relay (part number REL2). This device will allow for two controllers to share the same master valve with out any issues

:The few limitations include

- .Only one controller can operate at a time
- A delay of at least five minutes between the operation of controller #1 and controller #2

.is desirable

.Electrical alerts will apply for each controller •


.Steps for set up

.1 .Wire the relay according to the drawing below

.2 Set up the master valve in the the app for both controllers using the normal instructions
in the article [here](#) ^[19]

.3 .Set up a new master valve using the app for controller #2 as per normal instructions

.REL 2 is NEVER connected to high voltage. It is for 24 VAC devices only



Master Valve Wiring and Software Setup

:In this article, we will discuss the following topics

- Brief Summary
- Operation Chart
- Wiring
- Software Setup
- Master Valve (P/MV) Operation per zone

Brief Summary

A master valve is a normally closed valve installed at the supply point of the mainline that opens only when the automatic system is activated. Zone valves are the individual valves that operate a group of sprinklers or drip emitters. Hydrowise controllers support 6 - 54 zone

valves, depending on the model. Typically one zone valve is turned on at a time and controls the irrigation in a specific area of your garden. Whenever one of the irrigation zone valves is told to open by the controller, the controller also signals the master valve to open. The purpose of the master valve is to shut off the water to the irrigation system when none of the .zone valves are operating

IMPORTANT: The default setting for the Pump Start Relay/Master Valve is **NOT** **.ASSIGNED (OFF)** in the software settings

Operation Chart

Set Master Valve Operation	Controller Model
ON or OFF by All Zones	HC
ON or OFF by All Zones	PRO-HC
ON or OFF by Zone or All Zones	X2 w/WAND WiFi Module
ON or OFF by Zone or All Zones	HPC
ON or OFF by Zone or All Zones	HCC

Wiring

- .Route the master valve wire between valve location and the Hydrowise controller


.1
- Attach the common wire to either solenoid wire. This is most commonly a white-colored

.2
- wire. Attach a separate control wire to the remaining wire of each master valve solenoid.
- .All wire splice connections should be done using waterproof connectors
- .Route wire through the conduit or one of the openings on the bottom of the cabinet


.3
- Strip ½" (13 mm) of insulation from the ends of all wires. Secure the valve common wire

.4
- .to the **"COM"** (Common) terminal. Attach the opposite control wire to the M/V terminal



Wiring Illustrations	
PRO-HC	HC




HCC



HPC




X2 w/WAND WiFi Module



NOTE: With an HC Hydrowise controller, any one of your 6 or 12 zones can be configured to act as a master valve. We usually recommend wiring to the last zone not used in the .controller

Software Setup



This setup option is prompted when you first go through the initial setup wizard in the .software



In the event, you need to change this in the software after the setup wizard, please refer to the instructions below

1. Sign in to your [Hydrawise](#) ^[20] account
2. Click on **ZONES AND SCHEDULES** for the PC or **ZONES** if using the mobile app
3. Choose **YES** from the drop-down above the zones. If you have an HC controller, then you choose the zone number that you have the master valve wired to

X2 w/WAND, PRO-HC, HPC, and HCC Controllers	HC Controller



Master Valve (P/MV) Operation per Station


Selecting a master valve to be on/off for an individual zone, can be done when editing the zone in zones and schedules under advanced settings. This option is useful when one zone is using city water and another is using it from another source. This option is for X2 .w/WAND, HPC, and HCC controllers only

.Please follow the steps below to change this setting

From the **ZONES AND SCHEDULES** page, click on the (✎) icon on the zone you would .1
like to edit

.2 Click on **ADVANCED** located on the top blue search section

.3 Select Use **GLOBAL MASTER VALVE SETTING** to keep this circuit on or select
.DISABLE MASTER VALVE to turn this circuit off



Sprinklers Running with the Controller Off or Unplugged

There are two reasons why sprinklers would continue to run with the controller **Off** or **:Unplugged**

- It's possible your valves were opened manually. Locate your valve box(es) and turn the solenoid(s) clockwise until snug. The solenoid is located on top of the valve and looks like a cylinder with two wires protruding out of it

• It's also possible that debris in the valve is causing the diaphragm to remain open

To fix this problem

- 1. Disassemble the valve
- 2. Rinse all parts with clean water
- 3. Reassemble the valve

If you cannot locate your valves, contact the contractor who installed the system

Cleaning the Diaphragm on a Hunter Valve