


# Account - Location


The location is synchronized after the settings are configured in the Hydrawise app. The time zone and forecast are automatically set when the **location** is entered during the app set up wizard process. In the event this setup needs to be changed or updated, we recommend editing the setting in the application under the Weather station tab.

Please view the steps and screenshots to set the weather station location:


1. Click on the "**Controller Settings**" tab on the left hand side.
2. Select "**Weather Stations.**"
3. Enter the "**complete street address.**"
4. Regional setting will "**automatically**" be updated to the correct timezone.



## STEP 2



## STEP 3



**NOTE:** If your controller is running in offline mode (WiFi is disabled) then the date, time and time zone will be shown on a GREEN background and can be changed.