

Changing Run Times in Standard Mode

If you need to edit the **Run Time** for each station (zone) in **Standard Mode**, review the steps below to access this feature. The following fields are also available:

| Time and Frequency | |
|---------------------|--|
| Program Name | Choose the program name and program type. |
| Start Times | Choose the water days and up to six start times. |
| Run Times | Choose the number of minutes each zone will run for each start time. Run times must be from 1 min to 23 hrs and 59 mins. |
| Schedule Adjustment | Choose how to adjust the watering time based on your weather triggers. |
| Monthly Adjustment | Monthly adjustments can be made using a chart as well. This will allow the run times set in a program to change by month as a global percentage (e.g.; June 80%, July 90%, August 100%). |

Edit Run Times

1. Sign in to your [Hydrawise account](#).^[1]
2. Click on **Zones** at the bottom of the app or **Zones and Programs** on a web browser from the home dashboard.
3. Select **Programs**.
4. Select the (✎) icon for the program that requires the change.
5. Select **Next 2X** in the zone details.
6. Click on **Select All Zones** to appear in the right selection bar.
7. Enter the watering **Run Time** in minutes for each zone.
8. Select **Done**, then **Ok** to save.

