

# Sensors - Klik Sensor Status

Please take note of the sensor states below once you've successfully set up your sensor through the Hydrawise application.

## Normally Closed (Default Setup) All Hunter CLIK Sensors

Sensor Status		
<b>GREEN</b>	Dry - Not Stopping Irrigation	Water
<b>RED</b>	Wet - Stopping Irrigation	No Water

**Note:** A good example would be a simple switch where closed would represent **ON** position and open would mean the **OFF** position.

For more information on configuring sensors, check our guide [here](#) <sup>[1]</sup>.