

# Controller - Function Paths

Below is a list of function paths for use with the controller interface in both online mode and offline mode.

## ONLINE MODE

**Change Wi-Fi/Check Status:** Home>Settings>Wireless>Select a Setting to Modify

**Controller Status:** Home>Status>Controller Status

**Program Expander:** Home>Status>Expansion Modules

**Manually Run Zone(s):** Home>Zones>Select Zone> Run>Enter Time>OK

**Model:** Home>Status>Controller Status

**Network Status:** Home>Status>Network

**Reboot Controller:** Home>Settings>Config>Reboot Controller

**Reset Controller:** Home>Settings>Config>Factory Default

**Run Wizard:** Home>Settings>Run Wizard

**Sensor Status:** Home>Status>Sensor

**Serial Number:** Home>Status>Controller Status

**Server Status:** Home>Status>Controller Status

**Test Network:** Home>Status>Network>Test Network

**Test Zone:** Home>Status>Zone Tester

**Time and Date:** Home>Status>Time

**Version Number:** Home>Status>Controller Status

**OFFLINE MODE (Versions 3.33 and below)**

**Note:** Changes can be done in offline mode only when Wi-Fi is disabled.

**Adjust Time:** Home>Settings>Offline Settings>Time

**Disable Wi-Fi:** Home>Settings>Offline Settings>Disable Wi-Fi

**Program Expander/Check Status:** Home>Settings>Offline Settings>Expansion Modules

**Program Sensor/Check Status:** Home>Settings>Offline Settings>Sensors

**Program Start Times:** Home>Settings>Offline Settings>Program Start Times

**Set Seasonal Adjust:** Home>Settings>Offline Settings>Seasonal Adjust

**OFFLINE MODE (Version 4.01 Standard Mode)**

**Note:** Changes can be done in offline status only when Wi-Fi is disabled.

**Adjust Time:** Home>Settings>Offline Programs and Settings>Time

**Disable Wi-Fi:** Home>Settings>Offline Programs and Settings>Disable Wi-Fi

**Program Sensor/Check Status:** Home>Settings>Offline Programs and Settings>Sensors

**Start Times:** Home>Settings>Offline Programs and Settings>Offline Programs>Edit Start Times

**Water Days:** Home>Settings>Offline Programs and Settings>Offline Programs>Edit Water Days

**Zones:** Home>Settings>Offline Programs and Settings>Offline Programs>Edit Zones

**Set Seasonal Adjust:** Home>Settings>Offline Programs and Settings>Seasonal Adjust

