


Account - Controller Configuration

To change the configuration of your controller, select **Controller Settings** from the menu on the left hand side.

Please view the screenshot below to access this feature:



Controller Settings

Configuration Options	
Controller Name	The name of your controller
Serial Number	The controller's serial number. Click 'Remove Serial' to remove the serial number and replace it with another physical controller

Notification Email	The email address notifications are sent to when the controller is offline, or Hydrawise needs to contact you (for example when your subscription plan is about to end)
Notify	The amount of time that your controller is offline for before we notify you
Units	The units used for reports, alerts and elsewhere in the app
Inter Zone Delay	The number of seconds to insert between each zone watering when calculating scheduled
Master Valve Delay	The minimum number of seconds that the master valve should be active before any zone starts
Hide password	If set to yes, this will hide your wireless password on the controller. If your controller is in a publicly accessible area we recommend you hide your password.


Controller Settings Page

Controller Settings for My Controller

<p>CONTROLLER</p> <ul style="list-style-type: none"> NAME Hunter Industries SERIAL NUMBER V114563 Remove Serial STATUS Linked MODEL HC 6 Zone Controller INSTALL DATE Mon, 19 Sep 16 02:07:37 +0000 SOFTWARE 	<p>OFFLINE NOTIFICATIONS</p> <ul style="list-style-type: none"> NOTIFICATION EMAIL anthony+4@hydravise.com NOTIFY After no contact for 1 day
<p>INTERNET SETTINGS</p> <ul style="list-style-type: none"> OFFLINE MODE HIDE WIFI PASSWORD No DISABLE LOCAL ACCESS No 	<p>REGIONAL SETTINGS</p> <ul style="list-style-type: none"> TIMEZONE America/Los_Angeles
	<p>VALVE DELAYS</p> <ul style="list-style-type: none"> INTER ZONE DELAY 0 seconds MASTER VALVE DELAY 3 seconds

Expansion Modules

This section you can see your expansion modules and when they last made contact. You can also add or remove expansion modules. Up to 2 expansion modules can be added to a single Hunter HC controller.



When you add an expansion module, you will need to give it a name and specify the ID number that you selected when setting up the module. This number needs to match the number at the physical expansion module as well.

Edit an expansion module

Expansion Module Name

This is a name for the expansion module

Expander ID

Each expander module has a selectable ID between 1 and 5. This must match the ID selected on the expander unit.

Cancel OK

Offline Water Adjustments

Offline water adjustments allow the controller to automatically adjust the amount of watering on a month- by-month basis if the controller is in an Offline mode (ie. if is not connected to the internet).

<input type="checkbox"/>