Adding a Contractor

Overview

If you have a contractor in your area where you would like them to manage or view your controller settings when necessary, please follow the steps below:

Steps

- 1. Sign in to your <u>Hydrawise account.</u> [1]
- 2. Select the **Menu** icon (a) on the upper left-hand side of the app. If accessing from a web browser, click on the join the upper right-hand side.
- 3. Select Account, then Account Details.
- 4. Scroll to the bottom and click the Dicon under Privacy Settings.
- 5. You will now have the option to Search and Select a contractor in your area filtered by the radius selected.