

My controller says, "Please link to your account." What does this mean?

Your Hunter HC controller must be linked to your Hydrawise account so that it can sync with your settings and water appropriately.

See [Linking Your Controller to Your Account](#)^[1] for further instructions.