

When will my zone next run using smart ET watering?

With Smart Watering, your zone will run when your estimated soil moisture reaches zero.

To check your estimated soil moisture, go to the **Zones and Schedules** page. Then look at the **Schedule Adjustments** field for the zone you want to check. This will display the estimated moisture level. When the soil moisture reaches 0%, the zone will water.

You can also check your estimated soil moisture balance in the **Reporting** section of the app.