



Does my controller reset when there's no signal?

Yes. It is normal for Hydrowise controllers to reset if there is a problem with your signal, including signal drop or loss. This helps re-initiate a connection.

NOTE: This does not happen if your Wi-Fi signal is strong. It only happens when a poor Wi-Fi signal is received by the controller.