




Units of Measurement


For information on changing the units of measurement in your account, please see the steps below:

1. Click **"Account Details"** under the settings tab on the upper right hand side.
2. Click the  icon in the user settings box.
3. Scroll down to choose the correct units of measurement. Screenshots below:



Step 3

Edit User


[Change picture](#)

Name

Hydrawise Contractor

Email Address

contractor@hydrawise.com

Units of Measurement

Celsius & Millimeters

Language

English

Change Password

Cancel

OK