


Zones and Schedules - Standard

Standard Mode allows you to create traditional irrigation programs using Programs A, B, and C — just like Hunter X-Core® or Pro-C® controllers. This mode offers less flexibility than Hydrawise Advanced Mode. Key features include:


- Six programs available with six start times each
- Zones already labeled in the program for easier selection
- Once a zone is selected, the zone run time is visible
- Predictive Watering™ options that only apply to that program


The steps and screenshots below show how to set a program and customize zones:

Click **"Zones & Schedules"** from the home Dashboard. Then select **"Programs."**




Select the "+" button to start building the program.






Choose a "Program Name" and a "Program Type."



Select the "Watering Days" and "Start Times." Enter the start times you want this program to start. Each program can have up to four start times.



Program Name ▶ **Start Times** ▶ **Run Times** ▶ **Schedule Adjustments**

Watering Days
Select the days of the week to water

Selected Days of the week ▼

SN
 M
 T
 W
 TH
 F
 S

Start Times
Enter the times you want this program to start. You can add up to 4 start times

06:30 PM

+ Add Start Time

Select **"Run Times."** Enter your desired times in minutes.

Step 5

Program Name ▶ **Start Times** ▶ **Run Times** ▶ **Schedule Adjustments**

Select Zones
Please select and enter run length for the zones you want to apply to

[Select All Zones](#)

<input type="checkbox"/> Zone 1		
<input checked="" type="checkbox"/> Zone 2	↔	10 minutes
<input type="checkbox"/> Zone 3		
<input checked="" type="checkbox"/> Zone 4	↔	10 minutes
<input type="checkbox"/> Zone 5		
<input checked="" type="checkbox"/> Zone 6	↔	10 minutes

Choose the following options for the Time-Based Schedule:

- Predictive Watering adjustments: Adjusted based on your water triggers
- Monthly adjustments: Can be made using a chart as well
- Click **"OK"** when adjustments are complete

Step 6

Program Name ▶ **Start Times** ▶ **Run Times** ▶ **Schedule Adjustments**

Predictive Watering™
Adjust watering based on the following triggers

⏸ Don't water when:

- Forecast below 68°F
- 80%+ chance of rain
- 0.1in+ rainfall last day
- 0.4in+ rainfall last 7 days

[Edit monthly adjustments \(advanced\)](#)

✎ Adjust watering:

- Water 30% longer when above 86°F
- Water more often when above 86°F

Cancel ← Prev Next → ✓ OK

Click on **"Zones & Schedules"** from the home Dashboard. Then select **"Zones."**

Step 1

Select the **"+"** button to start building the zones. Choose a **"Zone Name,"** a **"Zone Number,"** and a **"Zone Icon."**

Step 2

Zone Details > Cycle & Soak > Advanced

Zone Name
Assign a name for this irrigation zone

Choose whether you want to enable the Cycle & Soak [1] feature.

Step 3

Zone Number
Choose the zone number that this zone is wired to on your Hunter controller

Zone Details > Cycle & Soak > Advanced

Cycle & Soak
Cycle and soak reduces runoff from each zone by pausing an irrigation cycle ⓘ

Do not enable cycle and soak
 Enable cycle and soak

Cancel Next > OK

Finally, the "Advanced" section lets you select a "Watering Adjustment" as a percentage.

Step 4

Zone Details > Cycle & Soak > Advanced

Water Adjustment
Fine tune your watering if your zone appears to be too dry or wet

Water less Normal Water more

Water for normal watering length

Cancel OK