WAND - Factory Reset

1. Press and hold the WAND button for 5 seconds and **Fdr** will appear on the controller LCD.
2. The module **LED** will turn off.
3. Release the button when the solid amber LED appears. The word **DONE** will appear on the controller LCD.
4. Return to the online setup wizard in your Hydrawise controller settings account page to reconnect **WAND** to Wi-Fi.



Copyright 2024 Hunter Industries. All Rights Reserved.