



WAND - Factory Reset

- 1. Press and hold the WAND button for 5 seconds and **Fdr** will appear on the controller LCD.
- 2. The module **LED** will turn off.
- 3. Release the button when the solid amber LED appears. The word **DONE** will appear on the controller LCD.
- 4. Return to the online setup wizard in your Hydrowise controller settings account page to reconnect **WAND** to Wi-Fi.

□