

# X2 - Programming Offline with No WAND Installed

X2 dial and button functions are disabled when Wi-Fi is on, as well as the existing schedule and settings. All programming is managed from the Hydrawise<sup>™</sup> online software. Manual Station, Manual Program, and Test All Stations can be activated at the controller. For full offline functionality without the WAND module installed, click [here](#) <sup>[1]</sup>.