

Hunter®

 **Hydrawise™ Ready**
IRRIGATION CONTROLLERS

Hydrawise Software/App Owner's Manual



hydrawise.com

Table of Contents

Table of Contents	2
Hydrawise and End User Plans Overview	3
Upgrading Plan Using Credit Card	4
Can I have multiple controllers per account?	5
Picture Storage	5

Hydrawise and End User Plans Overview

The Hydrawise irrigation management system is **free** for most users worldwide. Hydrawise uses the award-winning forecasting technology provided by The Weather Company (which operates The Weather Channel and Weather Underground), as well as global Hydrawise Virtual Weather Stations (VWS), to meet the needs of the typical user.

However, some customers want to fine-tune their irrigation to provide even more water savings. The Hydrawise Enthusiast Plan gives you access to more weather stations, longer data storage times, instant SMS alerts, and improved weather history accuracy. It also provides the ability to monitor five weather stations at your location.



Learn more about our available plans to help save water, protect outdoor living spaces, and better understand irrigation in the table below.

Plans	Home	Personal Weather Station	Enthusiast
Description	Home Plan (free): Our standard plan offers free weather station connection, in-app alerts, reporting, and 1 user account	Personal Weather Station Plan (free): Offers a free connection to the homeowner weather station, in-app alerts, reporting, and 1 user account	Enthusiast Plan (1-year subscription): Use multiple weather stations for hyperlocal weather, receive SMS alerts, 5 user accounts
SMS (Text) Alerts Per Month	N/A	N/A	5
# of Controllers	3	3	5
Users	3	1	5
# of Weather Stations	Hydrawise VWS or local airport (1 max)	Hydrawise VWS or local airport (1 max)	Hydrawise VWS or local airport (5 max)
History Storage	30 days	30 days	365 days
Schedule Adjustments	About 1 hour before your first start time	About 1 hour before your first start time	About 1 hour before each start time
	We receive the forecast		We receive the

Weather Forecast Updates	at approximately midnight in your local time	We receive the forecast at approximately midnight in your local time zone	forecast at approximately midnight in your local time zone
Weather History Updates	We receive the last 24 hours of history at approximately midnight in your local time zone	We receive the last 24 hours of history at approximately midnight in your local time zone	We receive the last 24 hours of history approximately 1 hour before each start time in your local time zone
How to Obtain?	Automatically applied to each new account — for free!	This is an exclusive Plan available to customers who share their weather station on the Weather Underground platform; Learn more ^[1]	Purchase through the App ^[2] or from your contractor.
Plans and File Storage	25 MB	25 MB	100MB

Upgrading Plan Using Credit Card

The Hydrowise system is free for most users worldwide. The [Weather Underground](#) ^[3] award-winning forecasting and airport weather stations meet the needs of the typical user. For those interested in even more water savings, the hyper-local weather feature in the Enthusiast Plan provides access to more than 100,000 personal, airport, and official weather stations, and allows you to monitor five weather stations at your location. To upgrade or renew your current plan, please follow the steps below:

1. Sign in to your [Hydrowise account](#) ^[4].
2. Click on the **Menu** icon () on the upper left-hand side of the app.
3. Under **Account**, click **Account Details**. Click the **My Account** icon on the upper right-hand side from the web browser.
4. Under **Plan Details**, click on the () icon.
5. Select **Homeowner Plans**.
6. Select **Plan**. You will see options for purchasing a new plan.

Can I have multiple controllers per account?

Yes. Each [plan](#) ^[5] has a limit on the maximum number of controllers permitted per account.

Homeowner & End User Plans

Subscription Plan	Max Controllers
Home Plan	3
Enthusiast Plan	5

Contractor Plans

Subscription Plan	Max Manageable Controllers
Contractor Starter	25
Contractor	75
Bronze	150
Silver	250
Gold	400

Note: As a contractor, the maximum manageable controllers include your own.

For example: If you have five controllers under your Contractor Starter account, you cannot add any more controllers. This means you will be required to upgrade to a Contractor Plan to increase your limit. In addition, if one of your customers has five controllers, this adds to the maximum number of manageable controllers.

Picture Storage

As part of our Hydrawise features, you get a set allowance for data. That way, you can upload personalized photos for your zones, file sheets, and other data for your customers if you are a contractor.

The table below shows the data allowance based on your plan:

Home Plans	Capacity
Free (Home Plan & Personal Weather Station Plans)	25 MB
Enthusiast Plan	100 MB

Contractor Plans	Capacity
Contractor Starter Plans (Free)	25 MB
Contractor Plan	100 MB
Bronze Plan	100 MB
Silver Plan	150 MB
Gold Plan	200 MB

Auto resize is also available. This automatically reduces the file size of image uploads based on the following conditions:

1. If the file size is greater than 1.5 MB, we reduce image size to 2000 pixels.
2. All other files are converted to JPG.