HCC - How do I connect the controller to the Internet?

Using the Connection Wizard

From Home screen touch Settings button then the Wireless button. Select your wireless network from the list shown on the controller display and press the Confirm button on screen. Enter your wireless password and press the OK button on keyboard.

Important: If your network is not listed then check that the unit is within wireless range. Make sure you press the OK button after you've entered your password. Pressing the **HOME** or **BACK** buttons will not save your changes.



1. Touch to change wireless access point.
2. Current wireless connection status.
3. Touch to change wireless security type.
4. Touch to change wireless password.

When connecting to your wireless, the Wi-Fi icon at the bottom right of the controller screen will flash. Connecting takes about 30 seconds and when successfully connected the Wi-Fi icon will remain solid.

Copyright 2024 Hunter Industries. All Rights Reserved.

Copyright 2024 Hunter Industries. All Rights Reserved.