

# Advanced versus Standard Mode

Your Hydrowise system can be configured in two programming modes: Advanced and Standard. The four charts below describe the features and benefits of each of the modes. For more information on switching modes, [click here](#) [1].

**Important:** In **Advanced Mode**, every program and individual zone counts as its program. It is easy to exceed the 6-program limit. When this happens, the programs can get too large and exceed the controller's memory. This extra programming could result in an error message **Configuration To Large**.

## Standard Mode

Features	Yes/No
Industry <b>Standard</b> Programming	Yes
Stations can have different run lengths	Yes
Multiple start times from the same program	Yes
Odd / Even / Interval Watering	Yes
Name Programs or Start Times	Yes
Preconfigured Schedules	No
Time - Based Watering	Yes
Virtual Solar Sync Watering	Yes
ET (Smart) Watering	No
Water More often when hot	No

Controller Model	# Programs	# Start times per program	Total Start times per controller	Number of concurrent stations	MV allocation by the station
X2 with WAND	3	6	18	1 + MV	No
Pro-HC (PHC)	6	6	36	1 + MV	No
Pro-C Hydrowise (HPC)	6	6	36	1 + MV	Yes
HCC Controller (HCC)	6	6	36	2 + MV	Yes

Use **ADVANCED MODE** to create irrigation schedules with zone-based programming, which enables complex watering programs and small station count controllers. **NOTE:** The X2 controller model is not compatible with advanced mode.

**IMPORTANT:** The controller model X2 with WAND does not have the **ADVANCED MODE** feature so this dropdown will not appear in the software.

## Advanced Mode

Features	Yes/No
Industry <b>Standard</b> Programming	No
Stations can have different run lengths	No
Multiple start times from the same program	No
Odd / Even / Interval Watering	Yes
Name Programs or Start Times	No
Preconfigured Schedules	Yes
Time - Based Watering	Yes

Virtual Solar Sync Watering	Yes
ET (Smart) Watering	Yes
Water More often when hot	Yes

<b>Controller Model</b>	<b># Programs</b>	<b># Start times per program</b>	<b>Total Start times per controller</b>	<b>Number of concurrent stations</b>	<b>MV allocation by the station</b>
HC Controller (serial number C0) - Old model	N /A	N /A	N /A	1 + MV	No
HC Controller (serial number 05) - New model	6	6	36	1 + MV	No
Pro-HC (PHC)	6	6	36	1 + MV	No
Pro-C Hydrowise (HPC)	6	6	36	1 + MV	Yes
HCC Controller (HCC)	6	6	36	2 + MV	Yes