



# Performing a Reboot or Factory Default at Controller

If you are having issues connecting to your Wi-Fi network, it is a good idea to reboot and/or perform a factory default at the controller. You can follow the steps below to perform a reboot on your controller. This can help reestablish WiFi if you are having communication issues. The reboot will not erase any settings in your controller.

1. Select **Settings**.
2. Select **Configure**.
3. Select **Reboot Controller**.



If the reboot procedure did not help with the connection, please follow the steps below to perform a **Factory Default** reset on your controller. When the controller goes back online, the settings in the software will sync back into the controller within a few seconds.

1. From the home screen, select **Settings**.
2. Select **Config**.
3. Select **Factory Default**.
4. Select **Erase config**.
5. Select **Ok** to start.
6. Select **Ok** to scan for networks.
7. You can choose your **2.4g Network** from the list provided on the screen.
8. Select **Confirm**.
9. Enter **Wireless Network** and select **OK**.
10. Select **Continue** to perform a network test.

The controller is now ready for new configuration settings manually or automatically through synchronization with your Hydrowise account.