Why did my system not water and it shows not scheduled?

If the irrigation system does not water on the scheduled day, you may have a cancellation caused by a sensor or a water trigger. The Reports tab titled will indicate if either has occurred (e.i., wet rain sensor).

View Canceled Watering

- 1. Sign in to your Hydrawise account. [1]
- 2. Click the **Reports** icon (a) at the bottom or click **Reports** if using your computer (PC) from your home Dashboard.
- 3. Click the Report Schedule.
- 4. View the zones that were scheduled to run that day. If you see lines crossed through any of the zones, this indicates a **Sensor** or **Water Trigger** canceled the watering.

Sensors

Sensors will automatically cancel irrigation 30 days in advance but revert to the normal state (not stopping irrigation) when the sensor switches back. This could be several hours or days as it depends on the current climate conditions.

Aborted Due to Sensor Input

 Weather sensor is active (rain sensor, wind sensor or moisture sensor) Schedule will cancel indefinitely until sensor status returns to normal.

Water Triggers

Scheduling will be canceled based on how each trigger is set.

· Aborted Due to High Probability of Rain

The forecast chance of rain is higher than the trigger, and the schedule will reset/check the following day again.

Aborted Due to High Forecast of Wind Speed

Local wind speed is higher than the mph set in the trigger, the schedule will reset/check the following day again.

Not Watering Due to Low Temperature

 Forecast High Temperature is lower than the temperature set in the trigger, the schedule will reset/check again the following day

· Aborted Due to High Weekly Rainfall

• The total amount of rain for the last 7 days is higher than the trigger, the schedule will reset after the last 7 days is less than trigger

Aborted Due to Rainfall Higher last 24hr

• Previous day's rainfall is higher than set in the trigger, the schedule will reset/check again the following day