


Why did my system not water and it shows not scheduled?

If the irrigation system did not water on the scheduled day, you may have a cancellation caused by a sensor or a water trigger.

View Canceled Watering



1. Login in to your Hydrawise account. Click the **REPORTS** icon  at the bottom or click **REPORTS** if using your computer (PC) from the home Dashboard.
2. Click the report **WATERING SCHEDULE**.
3. View the zones that were scheduled to run that day. If you see lines crossed through any of the zones, this indicates a **SENSOR** or **WATER TRIGGER** canceled the watering.



Sensors

Sensors will automatically cancel irrigation 30 days in advance but will revert to the normal state (not stopping irrigation) when the sensor switches back. This could be several hours or days.

- **Aborted Due to Sensor Input**
 - Weather sensor is active (rain sensor, wind sensor or moisture sensor) Schedule will cancel indefinitely until sensor status returns to normal.

Water Triggers

Scheduling will be canceled based on how each trigger is set.

- **Aborted Due to High Probability of Rain**
 - Forecast chance of rain is higher than the trigger, the schedule will reset/check again the following day
- **Aborted Due to High Forecast of Wind Speed**
 - Local wind speed is higher than mph set in the trigger, the schedule will reset/check again the following day
- **Not Watering Due to Low Temperature**
 - Forecast High Temperature is lower than the temperature set in the trigger, the schedule will reset/check again the following day
- **Aborted Due to High Weekly Rainfall**
 - The total amount of rain for the last 7 days is higher than the trigger, the schedule

will reset after the last 7 days is less than trigger

- **Aborted Due to Rainfall Higher last 24hr**

- Previous day's rainfall is higher than set in the trigger, the schedule will reset/check again the following day