

# HCC - Connecting Sensors or Flow Meters (Optional)

The HCC Controller supports most open/closed contact types of sensors. Compatible Hunter flow meters and sensors include the [HC FLOW METER](#) <sup>[1]</sup>, [MINI-CLIK](#)® <sup>[2]</sup>, [RAIN-CLIK](#)™ <sup>[3]</sup>, [FREEZE-CLIK](#)® <sup>[4]</sup>, [WIND-CLIK](#)™ <sup>[5]</sup>, and [SOIL-CLIK](#)™ <sup>[6]</sup>.

For full details on the wiring and software setup, select one of the options listed below.

[Sensor Wiring and Software Setup](#) <sup>[7]</sup>

[Flow Meter Wiring and Software Setup](#) <sup>[8]</sup>